

Check to make sure you have all parts listed prior to installation. If anything is missing contact us immediately.

(1) Pedal Board face plate (Black or Silver)



1. Remove factory floor mat from car.
2. Remove plastic nut by rotating it counter clockwise, as shown in figure 1.
3. Install pedal board
4. Reinstall plastic nut as shown in figure 2
5. Reinstall floor mat or track mat as shown in figure 3.

