

## INSTALLATION INSTRUCTIONS FOR RUBBER GRIP PEDAL SET

Check to make sure that you have all parts listed prior to installation. If anything is missing contact us immediately.

### Step 1 (Clutch + Brake)

- A. Remove factory rubber pedal pads.
- B. Determine mounting holes based on any obstructions behind the factory pedal limiting the installation of hardware. We supply hardware for up to 4 mounting points per pedal. Most people choose 2 to 3 depending on model.
- C. Remove the rubber grips from the mounting holes.
- D. Place aluminum pedal covers over the top of the factory pedals.
- E. Mark holes for mounting.
- F. Center punch and drill holes.
- G. Install Rennline pedal covers using the supplied stainless screws and nuts.



(8) #8/32X5/8" Black S/S Truss Head Screw - MC91770A196

(8) #8/32 S/S Nylon Nut - MC90101A009

(4) Rubber grips

### Step 2 (Accelerator Pedal)

- A. Determine mounting holes the same way as done on the brake and clutch covers. Always take note of any obstructions on the back side of pedal prior to drilling.
- B. Position pedal cover over the top of the factory pedal making sure that there is no interference with carpet or pivot points.
- C. Mark, punch and drill holes using a 1/16 bit (For factory pedals with non-removable stainless steel inserts, you may need to drill a slightly larger hole)
- D. Using the supplied sheet metal screws, attach the pedal cover.



(3) #8x5/8" Black S/S Truss Screw - MC93406A196

(4) Rubber grips